

LITE ASH STRATOCASTER 0265002/521

SWITCH & CONTROL FUNCTION

5 WAY SWITCH POSITION					
					← 5WAY SWITCH POSITION
V&T1	V&T1,T2	V&T2	V&T2	V	← TONE CONTROL
					← NECK PICKUP
					← MIDDLE PICKUP
					← BRIDGE PICKUP
	← PICKUP IS ON				← PICKUP IS OFF

